



# Installation Instructions Storm Strips Kit

## Perimeter Seals

On the doorframe, measure the height required for each leg. Transpose the measurement(s) to each long leg and cut to length with hacksaw or chop saw. (We recommend 80 tooth chop saw blades.) Insert the foam seals into each leg and trim to length.

**NOW, LOCK THE DOOR.** This includes deadbolts, if present.

Press each leg against the door at 50% compression. Install 4 screws: 2 screws near the lock(s) and one screw near the top and bottom on each leg. Then unlock the door and test the hardware. (Hardware should work freely as before installation.)

Next, for the perimeter head, measure the width between vertical legs. Cut the aluminum head piece. Install the foam seal and install with each end in line with the vertical legs.

Next, recheck hardware. Then, install all remaining screws.

## Brush Sweeps

Remove the brush from the retainer. Measure the door width on the inside. Transpose the measurement to the aluminum retainer and cut to length. Then cut the brush retainer with lineman's pliers or diagonal cutter. (This will crimp the ends so that the brush does not fray.) Reinstall the brush into the aluminum retainer and install on the door with a slight bend at the threshold. (If no threshold, butt the brush against the floor.)

## Corner Pads

Clean the area in the door pocket just above the threshold. Peel the paper backer from the corner pad and install the wide side under the vertical seal. (Occasionally, the space between the door and doorjamb is too tight for corner pads. This makes the corner pad unnecessary.)

For commercial hardware with closers, alarms and panic devices, please call 844-543-8392 (toll-free) to discuss. Examples are shown at [www.stormstrips.com/page1.html](http://www.stormstrips.com/page1.html).